```
This document is more a dumping ground for the command block format I think the
protocol uses.
To see examples of the command block format see protocol.txt and vpl-px21.pdf
all numbers are in hex if i'm referencing a hex number in terms of a decimal num
ber i will give the hex number fist and the decimal number second surounded by (
the term char that I use comes from the C datatype which can hold one hex code
(00-ff)
IMPORTANT! -- usb control msg from libusb takes the direction as a part of reque
sttype this would normally be 0x00 for out and 0x80 for in
           -- Sony thinks otherwise, its 0xcl for in and 0x4l for out. (directio
ns from the perspective of the device, in means I'm taking input from the NetMD)
//-- standard request
(00/09) - 00 seems to come from the host 09 from the device, start of every bina
ry data chunk.
18 - Peripheral index - in this case the NetMD(18) or 81 which is used for a gen
eric reply code
06/07/43 - Read/write/move - All infomational commands seem to use 06 while data
changing commands use 07
        - actual track movement is done w/ 43
02 20 18- these 3 chars appear in everything except when 20 18 is replaced with
10 10
02 20 10- Track time, codec and bitrate all use this, track info vs track data?
(01/02) - 01 seems to deal with Disc info/Group info while 02 seems to be track
info
00 xx - track number(zero based track 1 is 00)
30 00 0a/01 - appear in all disc or track based commands and replies
00 (50/ff) - 50 appears in Set(07 style) commands and ff in get(06 style) comman
ds
00 00 0x - where x is buffer length for set functions
//-- odd man out - 4 char reply from device for buffer size needed to get data
01 is used in the buffer size report
81
<size>
0.0
```

protocol2.txt

Page 1/1

May 25, 02 16:02